

INSTALLATION FOR HORIZONTAL SLIDING PANELS

Wood blocking need to be at least 6" high.
It needs to be placed only at the top and the bottom of each unit.

